



1 STICK RUBBER PIECES INSIDE PLASTIC LIDS.

2 INSERT SPOKE AXLES IN RUBBERS PIECES.

3 TIE SLANT SPOKES TO STRAWS TO MAKE THE CAR FRAME.

4 MAKE A PAPER CONE.

5 STICK CONE TO FRAME. THE CONE MUST NOT TOUCH THE WHEELS. PLACE CAR ON A SMOOTH SURFACE AND BLOW HARD INTO THE CONE. YOUR FERRARI WILL SHOOT FORWARDS!!!

